Scoreboard Remote

Settings appear nearly unreadable, can you help?

The likely cause of this is due to using "Larger Text" setting under your device. Go to Settings -> Accessibility -> Display & Text Size. Once there, turn OFF the "Larger Text" feature and the ScoreCam settings should appear normal again.

More information about changing the font size on your device: <u>Change the font size</u> on your device

Unique solution ID: #1021 Author: Paul Last update: 2022-02-19 00:25