

App Settings

My screen keeps going dark on my device when I try to use the remote app. How do I fix this?

If your ScoreCam device is dimming try turning off the "Dim Display when Connected" on your ScoreCam device. Do this by going to Settings -> ScoreBoard Remote -> then disabling (turn off) "Dim Display when Connected".

If this issue is occurring on your Remote device you can change this by going to your device's Settings app -> Display & Brightness, and adjusting the brightness of your device there.

For more information on how to your change your device's brightness: [Adjust the brightness and color temperature on your device](#)

Unique solution ID: #1049

Author: Paul

Last update: 2022-02-19 00:27